



- See installation instructions
1. Lifting device
 2. Steering cable for power steering
 3. Water intake
 4. Air filter
 5. Oil filling
 6. Oil dipstick engine
 7. Oil filter
 8. Oil drain (with pump) engine
 9. Sea water filter
 10. Oil fill, outboard unit
 11. Oil drain outboard unit
 12. Oil dipstick, outboard unit
 13. Sea water pump
 14. Water filler cap fresh water
 15. Heatwateroutlet
 16. Heatwaterinlet
 17. Fuel connection for hose ID 9 (3/8)
 18. Fuel return connection for connection hose ID 9 (3/8)
 19. Fuel filter
 20. Speed control lever
 21. Connection box for extension cable
 22. Battery minus (-) connection
 23. Plus (+) connection for charging distributor
 24. Starter battery plus (+) connection
 25. Pump power steering (options)
 26. Servo cylinder (options)
 27. Center of gravity

5526

TAMD22P/SX