



- 1 OIL DRAIN
- H CONNECTION ELECTRICAL CONTROL
- G CONNECTION BATTERY POS. AND NEG.
- F CONNECTION OIL TEMP./PRESSURE
- E CONNECTION SHIFT SOLENOIDES
- D OIL DIPSTICK GEAR BOX
- C OIL FILLER GEAR BOX
- B SEA WATER OUTLET, HOSE I.D. 50mm
- A SEA WATER INLET, HOSE I.D. 50mm

BED AND HULL DIMENSIONS SEE DWG 3591375  
 ENGINE RELATED ITEMS  
 SEE ENGINE INSTALLATION DRAWINGS

A°	B	C
5	582	532
6	589	521
7	596	508
8	603	496
9	611	483
10	618	469
11	626	455
12	635	441
13	643	426
14	652	410
15	661	395
16	670	378
17	679	362
18	689	344
19	699	325
20	709	308
21	720	289
22	731	270
23	742	250
24	753	229

SYMBOLS, DIMENSIONS AND GENERAL NOTES SPECIFIC TO THIS TYPE OF ENGINE ARE NOT SHOWN		
INSTALLATION DRAWING PS		
INSTALLATION DRAWING PS		3591073
<b>VOLVO PENTA</b>		08