



- See installation instructions
- 1. Lifting device
 - 2. Steering cable
 - 3. Water intake
 - 4. Air filter
 - 5. Oil filling
 - 6. Oil dipstick engine
 - 7. Oil filter
 - 8. Oil drain (with pump) engine
 - 9. Sea water filter
 - 10. Oil fill. outboard unit
 - 11. Oil drain outboard unit
 - 12. Oil dipstick, outboard unit
 - 13. Sea water pump
 - 14. Water filler cap fresh water
 - 15. Heatwateroutlet
 - 16. Heatwaterinlet
 - 17. Fuel connection for hose ID 9 (3/8)
 - 18. Fuel return connection for hose ID 9 (3/8)
 - 19. Fuel filter
 - 20. Speed control lever
 - 21. Connection box for extension cable
 - 22. Battery minus (-) connection
 - 23. Plus (+) connection for charging distributor
 - 24. Starter battery plus (+) connection
 - 25. Pump power steering (options)
 - 26. Servo cylinder (options)
 - 27. Cable steering
 - 28. Center of gravity

5524