


LETTER	NAME
A	OIL FILTER, ENGINE
B	OIL FILL, ENGINE
C	OIL DRAIN, ENGINE
D	OIL DIPSTICK, ENGINE
E	WATER DRAIN
F	LIFTING DEVICE
G	FUEL CONNECTION, I.D. 9,5 (3/8) NPT OR 6,35 (1/4) NPT
H	FUEL FILTER
I	ELETRICAL FUEL PUMP
J	THROTTLE CABLE SINGLE (HIDDEN)
K	WATER COOLED EXHAUST PIPE FOR HOSE I.D. 98,4 [3 7/8"]
L	STARTER MOTOR
M	FUSE PANEL (HIDDEN)
N	ELETRICAL CONNECTION ENGINE -INSTRUMENT PANEL
O	CIRCUIT BREAKER FOR TRIM PUMP
P	OIL FILL, POWER STEERING
Q	
R	STEERING CABLE
S	WATER INTAKE
T	OIL FILL, OUTBOARD UNIT
U	OIL DRAIN, OUTBOARD UNIT (HIDDEN)
V	OIL DIPSTICK, OUTBOARD UNIT
W	
X	SEE INSTALATION INSTRUCTIONS
Y	
Z	ENGINE FLUSH
AA	EXHAUST OVERHEAT SWITCH ENGINE ALARM IN SMALL PARTS KIT
AB	EVC SHIFT CABLE (HIDDEN)
AC	
AD	
AE	
AF	
AG	
AH	
AI	
AJ	
AK	

SYMBOLS, DESIGNATIONS AND GENERAL DRAWING METHODS STD 181-0005

The copying, distribution and utilization of this document as well as the communication of its contents to others without expressed authorization is prohibited. Offenders will be held liable for payment of damages. All rights reserved in the event of the grant of patent, utility model or registered design registration.

INSTALLATION DRAWING
4.3GI-200, 4.3GXI-225

VOLVO PENTA

21702252 | 01