



ECU UNIT





1 OIL FILLER CAP, ENGINE
2 OIL DIPSTICK, ENGINE
3 OIL DRAIN (WITH PUMP), ENGINE
4 OIL FILTER
5 WATER DRAIN, FRESH WATER
6 WATER FILLER CAP FRESH WATER
8 WATER DRAIN CHARGE AIR COOLER, SEA WATER
9 WATER DRAIN HEAT EXCHANGER, SEAWATER
10 FUEL FILTER
11 AIR FILTER
12 LIFTING DEVICE Ø21, (0.83)
13 ECU UNIT (BOAT MOUNTED)
14 OIL DIPSTICK OUTBOARD DRIVE
15 OIL FILL OUTBOARD DRIVE
16 OIL DRAIN OUTBOARD DRIVE
17 STEERING CABLE FOR POWER STEERING
18 TIE BAR
19 THROTTLE CABLE ATTACHMENT
20 AUX. STOP
21 FUSE
22 ECU CABLE HARNESS OUTLET L=15M (5 FEET)
23 ECU CABLE HARNESS INLET
24 FUEL SUCTION CONNECTION FOR HOSE I.D. 9.5 (3/8)
25 FUEL RETURN CONNECTION FOR HOSE I.D. 9.5 (3/8)
26 WATER INTAKE
CENTRE OF GRAVITY
X SEE TEMPLATE 7746008
SCALE 1:5

P/A
RELEASED

SYMBOL DESIGNATING AND GENERAL SYMBOLS PICTURES STD 191-0001 AND ISO 8625/2

ENGINE INSTALLATION
D3 - 5X-A

INSTALLATION DRAWING

VOLVO PENTA

3591629 | 01 | 1(1)

3591629-01 - Heruntergeladen von www.volvopenta.com 19.02.2008 22:05:01